

Auto-wrap Controlbox 2000 AW 4000/404

Notice:

By pressing "EXIT" more than 3 sek. You allways will be brought back to "Wrap-cycle" (Wrapp modus)

By pressing "MENU" more than 3 sek, the display contrast will be adjusted. "MENY" up = Stronger MENY down = weaker

Manual operation

Behind the rubberplug on the the rear side of the control box it is placed a switch for manual/automatic operation.

Please notice that the display does`nt work in manuel modus.



